

VOVERSTEEL KRYPTO

GAMING MONITOR SERIES

USER MANUAL

VOVERSTEEL KRYPTO

GAMING MONITOR SERIES

FULL HD RESOLUTION 1920×1080@165Hz



Important Safety Precautions

- 1. Please read all the instructions carefully before using this product.
- 2. BE SURE TO unplug the power cord when cleaning LCD. Never clean it with liquid detergent or spraying detergent, but wipe it with wet soft cloth. If it is still not clean, please use special detergent for LCD.
- 3. DO NOT use accessories not authorized by the manufacturer, other wise they may incur danger.
- 4. When disconnecting the power cord of display or power adapter, always remember to hold the plug instead of puling the wire to unplug the power cord.
- 5. Keep the display away from water sources such as bath tub, washbasin, sink or washing machine.DO NOT place the display on wet floor or near a swimming pool, or press LCD surface with fingers or hard objects.
- 6. The grooves and openings on the back and bottom of the shell are for ventilation purpose and also for guaranteeing the reliability of the elements and preventing them from overheating; in order to prevent the vents from blocking; DO NOT place the display on bed, sofa, carpet or other similar surfaces; DO NOT place the display near to or on heat radiator or heater; DO NOT put the display into embedded device, unless it is provided with adequate ventilating equipment.
- 7. Only the type of power source indicated on the nameplate applies to this display. If you have any questions on the type of power source you use, please consult the dealer of the display or local administration of power supply.
- 8. For safety, the display or the power adapter is equipped with three-pin plug power cord. The third pin of this plug is for grounding, and only applicable to socket that is correctly grounded. In case that your socket is not available for the plug, please contact electrician to replace the socket.
- 9. Since there is high voltage or other risks when the shell is opened or moved, please DO NOT repair the display by yourself, but request qualified maintenance staff to carry out.
- 10. In one of the following cases, please unplug the display or the power adapter and ask qualified maintenance staff for help:
- a. The power cord or the plug is impaired or worn.
- b. The display falls off or the shell is damaged.
- c. The display is obviously abnormal.
- 11. Please place the display in a cool, dry and well ventilated place.
- 12. Store the display in temperature range of -10°C \sim 60°C, beyond which the display may be damaged permanently.



1. Product Description

1.1 General

As a high-performance smart multi-frequency scanning display, it adopts active-matrix TFT-LED backlight liquid screen and is controlled with MCU digital technology. With compact and thin appearance and build-in power supply, it is suitable for narrow work space.

1.2 Packing list

Please check the following items in the packing case before installation:

- One LCD display (including the base)
- One DP cord, one power cord, one AC adaptor
- One user manual, One warranty card

If any of above items is missing, please contact with the dealer.

Attention: Accessories shall be subject to the real configuration. Please keep all packing materials well for product transport in the future.

2. Installation and Connection

2.1 Display installation

Installation instructions

This machine should be installed adjacent to an easily pluggable AC power socket.

For the sake of safety, we suggest that suitable wall-mounted bracket or base be used. In order to prevent injury, this machine shall be placed on a stable and level surface or fixed on a firm wall.


For wall-mounting, please ask a professional to do so. Improper installation may cause instability of this machine.

DO NOT place this machine in places with mechanical vibration.


DO NOT place this machine in places where insects are accessible.

DO NOT install this machine directly opposite to air-conditioner, otherwise its inner panel may be dewed and cause failure.

DO NOT place this machine in places with strong electromagnetic field, otherwise it may be interfered by the electromagnetic wave and get damaged.







2.2 Signal line connection


Connect the signal line to output interfaces signal of DP/HDMI/DVI signals of PC, and then connect the other end of the signal line to the corresponding signal input port of the display.

2.3 Audio output

This machine supports earphone and external speaker audio output.

3. Operation of Display

The OSD control buttons are shown as the figure. Models of the same product series are only different in button position and panel pattern, please refer to the practical model.





3.1 Power indicator light

When the display is working normally, the blue indicator light is on; when it is in the energy saving state, the indicator light blinks with red color; when the signals are sent again in the energy saving state, the machine will return to normal work. As the display is still powered in the standby state, for the sake of safety, the power cord should be unplugged when the display is not used.

3.2 Introduction to rocker functions

When the display is working normally, the blue indicator light is on; when it's in the energy saving state, the indicator light blinks with red color; when the signals are sent again in the energy saving state, the machine will return to normal work; when the machine is in the standby state, the red indicator light is on. As the display is still powered in the standby state, for the sake of safety, the power cord should be unplugged when the display is not used.











Rocker Up

Rocker Down

Rocker Left

Rocker Right

Press Rocker

	Initial state	Enter the function menu
Rocker Up	Signal source input	Move up
Rocker Down	Menu display	Move down
Rocker Left	Brightness adjustment shortcut key	Back to previous menu/adjust value-
Rocker Right	Volume adjustment shortcut key	Enter next menu/adjust value+
Press Rocker	Short press to start/ press and hold for 3s to turn off the machine	Confirm/press and hold for 3s to turn off the machine

3.3 Safety protection

When the video signals of PC exceeds the frequency range of the display, the horizontal and field synchronizing signals will be shut down to protect the display. Then, you have to set the PC output frequency to an acceptable range so as to make the display work normally.

7





4. Basic Troubleshooting

Phenomenon	Troubleshooting	
Light out/power indicator light is off	Check whether the display and the socket are well connected to power, and whether the display is in the shutdown mode.	
Image blurring, over-large, over-small, etc.	Enter the menu "Image Setting" and select "Auto Image Adjust" to automatically adjust the display.	
Image over dark	Enter the menu "Brightness and Contrast" to adjust the brightness and contrast of the display.	
Display over heat	Leave at least 5cm of distance for ventilation around the display and do not place articles on the display.	
Dark/ light spots when powering on	This is a normal phenomenon. It is due to the backlight illuminates unevenly at the initial phase of powering on caused by temperature difference. The backlight can illuminates normally after 20 minutes, and then the dark/light spots will be corrected.	
Image distortion, blinking, shaking	Check computer setting, select the correct resolution and readjust the refresh frequency.	
Power off noise	It is a normal phenomenon caused by display discharging in the process of powering off.	



5. Technical Specifications of Product

Panel size	27"	
Optimal working resolution	1920×1080@165Hz	
Power input	DC 12V/4.5A	
Blue-light filtering	Support	
Flicker-free	Support	
Requirements for working environment		
Barometric pressure Working temperature and humidity Warehousing temperature and humidity	86kpa~104kpa 0°C~40°C 20%~85% -10°C~60°C 10%~90%	
Packing size (L * W * T) and weight		
Unpacked size (L * W * T) (with base) Packing size (L * W * T) Net weight Gross weight	616×464.75×251.8mm 710x167x539mm 4.5 kg 7.1 kg	

Power supply management system

Mode	Power consumption	
Normal working	≤54W	
Standby	≤0.5W	

Remarks

All technical specifications in this manual and external packages are subject to change without further notice. In case that there is subtle difference between this manual and practical operation, please follow practical operation.

9






6. Instruction of Base Installation

Assemble the base to the stand with 2 sets of M4×10mm screws as pictured. (Figure 1) To remove the base:

- 1. Push the small slider in the position of the rear housing and base;
- 2. Lift up the base and take out the base in the direction of the arrow.



NOTE

Some of the contents in this manual may differ slightly from the final product.

